



LUXE

GREENERY WALLS



# Installation Materials

<b>FIXING SURFACE</b>	<b>FIXING MATERIALS</b>
timber fence	screw with large head / staple gun
wire fence	black zip ties
colorbond	metal screws (may require timber frame)
masonry / brick / render / stone / concrete	nylon plug + washer
plasterboard / gyprock	screw with large head + washer

# Installation Guide

- 1** If possible, we firstly recommend painting your Wall black for the best finish & to disguise any gaps through your greenery panel (optional).
- 2** Ensure plants on the panels are upwards facing. Over time, the plants will open.
- 3** To begin, start from the top & work left to right.
- 4** Using a spirit level, mark a line at the top of your wall to ensure your panel is straight.
- 5** Secure your first panel in all 4 corners & in the centre.
- 6** Connect the next panel using the hole & lug system on the sides of the grid & secure into place.
- 7** Repeat until finished.
- 8** Using side cutters or scissors, trim any excess grid or plant to finish off your new LUXE Greenery Wall.

(see a detailed description below)...

## **TIMBER FENCE**

Hold the panel up to the fence. Use a good quality staple gun (for Greenery panels with plastic backing) or screws with a large head & washer (for Greenery panels with galvanised backing). Secure all 4 corners & in the centre of the panel. Using cutters or scissors, trim excess foliage (if required).

## **WIRE FENCE**

Hold the panel up to the fence. Using black cable ties push them through the grid & around the fence & pull tight. Use as many cable ties as necessary in all 4 corners & in the centre of the panel. Using cutters or scissors, trim excess cable ties & excess foliage (if required).

## **COLORBOND FENCE**

Screw into metal fencing directly, using metal screws. Please note, you may have screws poke out of the reverse of the fence. We recommend making a timber frame to mount your panels on. Hold the panel up to the frame. Use a good quality staple gun (for Greenery panels with plastic backing) or screws with a large head & washer (for Greenery panels with galvanised backing). Secure all 4 corners & in the centre of the panel. Using cutters or scissors, trim excess foliage (if required).

## **MASONRY / BRICK / RENDER / STONE / CONCRETE**

Pre-drill hole with a hammer-drill & a masonry drill bit. Hammer in the nylon plug with a large head, making sure you have good coverage of the grid. Add more plugs where necessary to ensure panel is sitting flush on the wall.

## **PLASTERBOARD / GYPROCK**

If possible, screw directly into wall using screws with large thread and head. You may need to use washers as well to ensure you have a good grip on the grid. Secure in all 4 corners & in the centre of the panel to ensure the panel is sitting flush on the wall.

LUXE  
GREENERY WALLS

[www.luxegreenerywalls.com.au](http://www.luxegreenerywalls.com.au)

[luxegreenerywalls@gmail.com](mailto:luxegreenerywalls@gmail.com)

0409 470 299